

The first address for FOS/TAC analysis The new TitroLine® 6000




SI Analytics

a **xylem** brand



Application example for the water/wastewater and environmental analysis: FOS/TAC

An important parameter for monitoring the fermentation process of biogas plants is a titration method commonly known as FOS/TAC value. The TAC value is determined using 20 ml of a centrifuged sample from the fermenter titrated to pH 5.0 with 0.05 mol/l sulfuric acid. The FOS value is determined by a titration of the same sample to a pH of 4.4. Both titrated ml values are then used in the following calculation formula.



TAC = mI H_2SO_4 to pH 5.0 × 250

FOS = (ml H_2 SO₄ from pH 5.0 to pH 4.4 × 1.66 – 0.15) × 500

A different sample volume could also be considered. The FOS/TAC value is the average calculated value. The method and all parameters and calculation formulas are stored as a standard method in the TitroLine® 6000.

Ordering information:

Type No.	Order No.	Description
TL 6000-M2/50	285220090	TitroLine® basic unit with magnetic stirrer TM 235 and 50 ml exchangeable unit WA 50, with brown glass bottle for titrant, GL 45 and S 40-bottle adapter, tubes, drip tube and titration tip. With pH-combination electrode A 7780 1M-DIN-ID and buffer set.

SI Analytics GmbH Hattenbergstraße 10

55122 Mainz
Germany
Phone +49 (0)6131/66-5111
Fax +49 (0)6131/66-5001
support@si-analytics.com
www.si-analytics.com

Your distribution partner:

SI Analytics